ADJUSTMENTS:

THE TARGETS CAN INDIVIDUALLY BE ADJUSTED, LEFT AND RIGHT, IF NECESSARY. THEY ARE DESIGNED TO BE PLACED 4" ON CENTER BETWEEN TARGETS. IF ONE SEEMS A BIT OFF, YOU CAN MOVE THE INDIVIDUAL TARGET TO THE LEFT OR RIGHT BY MOVING THE CLEAR PLASTIC TUBING ON THE PIVOT ROD IN THE DIRECTION YOU WANT. BE SURE NOT TO SNUG THE TARGET BETWEEN THE TWO PLASTIC PIECES OR THE TARGET MAY NOT FALL FREELY.

THERE IS ALSO AN ARM ADJUSTING SCREW IN FRONT OF EACH TARGET. BY LOOSENING THE STOP NUT, YOU CAN ADJUST THE TARGET SCREW SO THAT THE TARGET FALLS PROPERLY WHEN THE COIL PULLS IN. FOR THE MOST PART, THE EDGE OF THE COIL ARM SHOULD LINE UP WITH THE EDGE OF THE TARGET.

THERE IS ALSO A PIECE OF SPRING METAL IN FRONT OF EACH TARGET. THIS KEEPS PRESSURE ON THE TARGET AND ACTUALLY AIDS IN THE TARGET FALLING. IF THE TARGET IS LAZY IN FALLING AFTER A HIT, A LITTLE MORE PRESSURE BY THIS SPRING METAL PIECE WILL HELP.

ADJUSTING THE STYLUS IS EASY BUT REQUIRES SOME THOUGHT. ADJUST THE STYLUS ONLY IF ALL THE TARGET SIGHTING IS OFF IN THE SAME DIRECTION, i.e., SIGHTING IS OFF TO THE LEFT ON ALL TARGETS. IF WHEN SIGHTING, 25% OR MORE OF THE PC BOARD CONTACT AREA IS IN CONTACT WITH THE STYLUS PIN AND A HIT IS NOT MADE (SWITCH TEST IS USEFUL FOR THIS) IT MAY BE THAT THERE IS NOT ENOUGH PRESSURE BETWEEN THE STYLUS AND CONTACT PIN ON THE PC BOARD. TO ADJUST THE PRESSURE, YOU MUST RAISE THE METAL BRACKET ON WHICH THE STYLUS BOARD RESTS. LOOSEN THE SCREWS ON THE LEFT AND RIGHT OF THIS BRACKET, MOVE THE BRACKET UP, AND TIGHTEN.

IF THIS DOES NOT APPEAR TO BE THE CASE, THEN THE STYLUS ARM CAN BE ADJUSTED. BY LOOSENING THE TWO (2) SCREWS 4' FROM THE END OF THE ARM. THE ARM CAN BE ADJUSTED IN ANY DIRECTION. ALWAYS RE-TIGHTEN THE SCREWS , OR THE ARM WILL SLOWLY MOVE OUT OF ADJUSTMENT.

AUDITS

PUSH AUDIT START/INC BUTTON TO ENTER AUDITS.
DISPLAY WILL SHOW "AUDIT". THEN SLIDE AUDIT FUNCTION 1 "AUD 1" ONTO DISPLAY.

AFTER A BRIEF DELAY, THE CONTENTS OF THE AUDIT FUNCTION WILL SLIDE ONTO DISPLAY. AT THIS TIME, THE FOLLOWING STEPS CAN OCCUR. PRESSING "AUDIT CLEAR" BUTTON WILL CLEAR CURRENT FUNCTION CONTENTS, OR PRESSING "AUDIT START" BUTTON WILL GO ON TO THE NEXT AUDIT FUNCTION. (THERE IS A 2-SECOND DELAY BETWEEN AUDIT FUNCTIONS.)